


ODYSSEY MOUNTING TEMPLATE & INSTRUCTIONS

Recommended for 2.4 kW, flex & plug models only



1. Hold this template level on the wall in the position you wish to mount your Odyssey & mark the wall through the paper at the "MARK" points indicated, ensuring both are a minimum of 50 cm above the floor level.

Note: If mounting on a plasterboard wall, studs must be behind the "MARK" points.

Remove the template and drill the two holes at the "MARK" points according to the following:

Wall Material	<u>Drill Diameter</u>
Masonry	3/16 inch or 5 mm
Wood	1/8 inch or 3 mm
Plasterboard on	1/8 inch or 3 mm
wooden studs	

Plasterboard only Not recommended

- 3. For masonry walls insert the red wall plugs provided.
- 4. Slide the washer followed by the rubber spacer (curved face first) onto each screw (8G x 30mm) provided and screw into the mounting holes until the rubber spacer compresses slightly.

- 5. Hold the heater up against the two screws so that the screw heads insert into the large hole of the keyhole slots on the back of the heater. Push the heater towards the wall against the rubbers & downwards so that the mounting screw heads slide upwards & into the slots of the keyholes.
- 6. If the heater is loose on the rubbers, lift it off the mounting screws, tighten them against the rubber spaces slightly and repeat step 5.
- 7. Insert the plug into the nearest power outlet & follow the Operating Instructions included with the heater
- 8. Pureheat warranty conditions only apply to heaters installed as described. Pureheat accepts no responsibility for the end result of installations carried out in accordance with these instructions.

PURFHFAT